


INSTRUCTION

REGIOLUX

Regiolux GmbH
Hellinger Str. 3
D-97486 Königsberg/Bay.
Telefon (0 95 25) 89-0
Telefax (0 95 25) 89 73 4
<http://www.regiolux.de>
e-Mail: info@regiolux.de




IP20

SRT-11A/0500 INKL. SRBK+SRTVL

1920 0013 ...

SRT-7A/0500 INKL. SRBK+SRTVL

1920 0012 ...




IP54

SRT-11A/0500 INKL. SRBKS+SRTVLS IP54


1920 0015 ...

SRT-7A/0500 INKL. SRBKS+SRTVLS IP54


1920 0014 ...



Option A Auspeisung



Option B Mitteneinspeisung



MONTAGE Option A

SRT-.A


I → SRTA-E

SRT

→ I

SRTA-11E / SRTA-7E

SRT-.A



SRTE
SRTES



10

11

Option 1

Option 2

I



MONTAGE Option B

