


INSTRUCTION


SRT-System 19..

SRT 1500 7x2,5 qmm
SRT 1500 5x2,5+6x1,5 qmm
SRT 2250 7x2,5 qmm
SRT 2250 5x2,5+6x1,5 qmm



REGIOLUX


Regiolux GmbH
Hellinger Str. 3
D-97486 Königsberg/Bay.
Telefon (0 95 25) 89-0
Telefax (0 95 25) 89 73 4
<http://www.regiolux.de>
e-Mail: info@regiolux.de



IP20 / 54 / 40


SRTA-11E

1920 0085 100



SRTA-7E

1920 0084 100




SRH

1920 0039 100



SRCS

1920 0034 100




SRD

1920 0033 100



SRCT


1920 0042 100



IP20


SRTV

1920 0020 100




SRTVL

1920 0031 100




SRBK

1900 400. 00.




SRBA

1900 100. 00.



SRTE


1920 0231 10.



IP40


SRTV

1920 0020 100




SRTVL

1920 0031 100




SRBKS

1900 500. 00.




SRBAS

1900 200. 00.



SRTES


1920 0235 10.



IP54


SRTVLS

1920 0050 100




SRBKS

1900 500. 00.




SRBAS

1900 200. 00.




SRTES

1920 0235 10.




SRT/SDT-MT





1920 9000 100




SRT-11A / SRT-7A

1920 008. 10.






SRG... > 2,9 kg



SRG... < 2,9 kg









INSTRUCTION

REGIOLUX

Regiolux GmbH
Hellinger Str. 3
D-97486 Königsberg/Bay.
Telefon (0 95 25) 89-0
Telefax (0 95 25) 89 73 4
<http://www.regiolux.de>
e-Mail: info@regiolux.de

Montage





SRT

VDE 0100

Leitung	N	PE	I max.								
			1	2	3	6	7	8	9	10	11
7 x 2,5mm ²	0		16 A	16 A	16 A					16 A	16 A
5 x 2,5mm ² + 6 x 1,5mm ²	0		16 A	16 A	16 A	10 A	10 A	1 A	1 A	1 A	1 A

SRB..

SRBK

SRBKs

SRBA / SRBAS

SRG

SRT

L3, L2, L1, PE, N

INSTRUCTION