










SDT-Basic




SDT 58/II BASIC	1825	2580	150
SDT 58/III BASIC	1825	3580	150

				SDCS	1890	0034	100
				SDCSE	1890	0044	100
				SDH	1890	0039	100
				KP	9282	9080	100
				SDRP	1890	0054	100
				RP 100	9280	9100	100
				RP 80	9280	9080	100
				RP 60	9280	9060	100
				RP 50	9280	9050	100
				SDD	1890	0033	100
				SDCT	1890	0042	100
SDTE		SDTSV		SDTE	1890	0231	100
				SDTSV	1890	0092	100
SDBK				SDBK	1883	7580	100
SDLA		SDLAD		SDLA	1890	0058	100
				SDLAD	1890	0068	100


1

SDH




2

SDD




3

SDCT




4

SDCS




5a

SDCSE




5b

SDCSE




6a

SDRP




6b

SDRP




6c

SDRP




7

SDTSV




8


SDTE



9a




9b




10

SDBK




11a

SDLA/SDLAD



11b

SDLA



11c

SDLAD

