

## Table of Contents

1.	General	2
2.	Carton Contents	3
3.	Tools and Materials Required	3
3.1	Tools	3
3.2	Materials	3
4.	Installation	3
4.1	Unpacking Stubbed Units	3
4.2	Mount the Housing into a Rack	4
4.3	Remove the Front or Rear Doors	4
4.3.1	Removing Front Door	4
4.3.2	Removing Rear Door	4
4.4	Secure the Cable	4
4.4.1	Strain-relieve using the Universal Cable Clamp (UCC)	5
4.4.2	Strain-relieve using Cable Ties	6
4.4.3	Strain-relieve the Cable Central Member	6
4.4.4	Grounding Armored Cable, if Armored Cable is Used	6
5.	Managing Cable	7
5.1	Install Preconnectorized Cable into Adapter Panels	7
5.2	Install Cable Using Buffer Tube Fan-out Kits	7
5.3	Install Connector Modules	8
5.4	Install Cable Using Splice Trays	9
5.5	Documentation	9
5.6	Reinstall Doors	9
5.7	Route Jumpers (Patch Cords)	9
6.	Connector Care and Cleaning	9
7.	Maintenance	10

# 1. General

This document describes the recommended procedure for installing the 4U Distribution Housing (p/n PDH-04U) (Figure 1). The unit fits into 19-inch utility racks and occupies four rack spaces. Individual components of the housing are shown in Figure 2.





Figure 1



Part Number	Dimensions (H x W x D)	Weight
PDH-04U	7 x 17 x 16 in. (18 x 43 x 41 cm)	11 lb (5 kg)

KPA-1360

Figure 2

## 2. Carton Contents

- 04U Distribution Housing with two mounting brackets
- Hardware Kit containing:
  - (1) Unit Identification label
  - (1 ft) Double-sided hook-and-loop strap
  - (12) Cable ties
  - (3 ft) Spiral wrap
  - (4) Routing clips
  - (1) Universal Cable Clamp kit
  - (1) Universal Cable Clamp bracket
  - (2) 6-32 Wing nuts
  - (8) #10-32 Phillips-head screws
  - (4) #12-24 Phillips-head screws
  - (1) 8-32 Phillips-head screw
  - (1) M6 flat washer
  - (1) U-shaped washer

## 3. Tools and Materials Required

### 3.1 Tools

- Phillips screwdriver
- Flat-tipped screwdriver
- 5/16-inch socket or wrench
- 11/32-inch socket or wrench
- Needle-nose pliers
- Cable stripping tools

### 3.2 Materials

Depending on your application, the following materials may be required:

- Preconnectorized Adapter Panels
- Universal Cable Clamp (UCC)
- Grounding kit (p/n FDC-CABLE-GRND) to ground armored cable
- Buffer tube fan-out (BTF) kits
- Splice tray bracket kit (p/n PC4-SPLC-12SR)

## 4. Installation

### 4.1 Unpacking Stubbed Units

If you are installing a stubbed unit, follow the directions provided with the shipping container to remove the stubbed unit from its packaging. Place the unit on a work surface to perform the preliminary work before mounting the unit into a rack.

## 4.2 Mount the Housing into a Rack

Attach the unit to the equipment rack using the four screws provided. Two screws are required per each side of the housing. The mounting bracket position may be changed to adjust the frontal projection from the rack (Figure 3).




Figure 3

If installing into a 23-inch rack, attach the adapter bracket (Figure 4) to both sides of the housing using the screws provided before installing the unit into the rack.

## 4.3 Remove the Front or Rear Doors

The doors can be removed to facilitate cable installation.

### 4.3.1 Removing Front Door

- Step 1:** Loosen the screw on the left side of the housing.
- Step 2:** Slide the screw toward the rear of the housing (Figure 5).
- Step 3:** Slide the door off the hinge pin.

### 4.3.2 Removing Rear Door

- Step 1:** Open rear door of housing.
- Step 2:** Flex the door and slide the door off one of the hinge pins.
- Step 3:** Remove the door from the other hinge pin.




Figure 4




Figure 5

## 4.4 Secure the Cable



**CAUTION:** Fiber optic cable is sensitive to excessive pulling, bending, and crushing forces. Consult the cable specification sheet for the cable you are installing. Do not bend the cable more sharply than the minimum recommended bend radius. Do not apply more pulling force to the cable than specified. Do not crush the cable or allow it to kink. Doing so may cause damage that can alter the transmission characteristics of the cable; the cable may have to be replaced.



**CAUTION:** If you are installing outside plant cable or temperature fluctuates widely along any part of the cable, the central member must be strain-relieved. Failure to do so may result in damage to the cable as temperature varies. If the entire length of cable is located in a controlled environment where temperature fluctuation is minimal, it is not necessary to secure the central members. The cable can be strain-relieved by sheath retention alone.


For cable sheath retention only, use the Universal Cable Clamp (UCC) or cable ties.

#### 4.4.1 Strain-relieve using the Universal Cable Clamp (UCC)

**Step 1:** Determine the location for cable entry into the housing.

**Step 2:** If installing outside plant cable, remove the membrane from the appropriate entry grommet (Figure 6).

Bracket Orientation for Top Cable Entry



Bracket Orientation for Bottom Cable Entry





Figure 6

**Step 3:** If installing indoor cable, remove appropriate cable entry plate as shown in Figure 7.

Bracket Orientation for Top Cable Entry



Bracket Orientation for Bottom Cable Entry




Figure 7

**Step 4:** Attach the UCC clamshell to the strain-relief bracket as shown in Figures 6 and 7 to allow installation of a second UCC if necessary.

**Step 5:** Attach the strain-relief bracket to the housing.

**Step 6:** Follow installation instructions provided with the UCC kit to secure the cable. Do not tighten yet to allow for cable adjustment if necessary.

## 4.4.2 Strain-relieve using Cable Ties

- Step 1:** Attach the cable tie to the strain-relief bracket in two places with cable ties as shown in Figure 8.
- Step 2:** Attach the strain-relief bracket to the housing.
- Step 3:** Allow room on the bracket to strain-relieve the cable strength member, if present.

## 4.4.3 Strain-relieve the Cable Central Member

 **CAUTION:** Corning recommends the use of safety glasses (spectacles) conforming to ANSI Z87 for eye protection from accidental injury when handling chemicals, cables, or working with fiber. Pieces of glass fiber are very sharp and have the potential to damage the eye.

 **CAUTION:** The wearing of cut-resistant safety gloves to protect your hands from accidental injury when using sharp-bladed tools and armored cable is strongly recommended. Use extreme care when working with severed armor. There will be a sharp edge where armor is cut. To minimize the chance of injury from the cut armor, cover the exposed edge with a wrap of electrical tape. To minimize the chance of injury from sharp-bladed tools, always cut away from yourself and others. Dispose of used blades and armor scrap properly.

- Step 1:** Install the U-shaped washer and the flat washer on the strain-relief bracket in the orientation shown using the supplied Phillips-head machine screw (Figure 8).
- Step 2:** Place the central member and yarn, if present, between the U-shaped washer and the flat washer.
- Step 3:** Wrap yarn around the screw in a clockwise direction and under the U-shaped washer.
- Step 4:** Tighten the screw.
- Step 5:** Trim off the excess yarn and central member.




Figure 8

## 4.4.4 Grounding Armored Cable, if Armored Cable is Used

If using armored cable, one grounding kit (p/n FDC-CABLE-GRND, purchased separately) is required to ground each armored cable. Follow instructions provided with the grounding kit to attach the hardware to the armored cable.

- Step 1:** Attach the other end of the ground wire from the armored cable to the equipment rack. The equipment rack must be grounded to the primary building ground.

- Step 2:** Remove the paint from the rack at the grounding location to ensure metal-to-metal contact. It is recommended to use an antioxidant on the bare metal to prevent corrosion.
- Step 3:** Or, attach the other end of the ground wire from the armored cable to a rack-mounted grounding bus bar that is grounded to the primary building ground.

## 5. Managing Cable

### 5.1 Install Preconnectorized Cable into Adapter Panels



**WARNING: Never look directly into the end of a fiber that may be carrying laser light.** Laser light can be invisible and can damage your eyes. Viewing it directly does not cause pain. The iris of the eye will not close involuntarily as when viewing a bright light. Consequently, serious damage to the retina of the eye is possible. Should accidental eye exposure to laser light be suspected, arrange for an eye examination immediately.



**WARNING: DO NOT use magnifiers in the presence of laser radiation.** Diffused laser light can cause eye damage if focused with optical instruments. Should accidental eye exposure to laser light be suspected, arrange for an eye examination immediately.

- Step 1:** Remove the blank panels from the front of the unit and replace with adapter panels (purchased separately).
- Step 2:** Clean connectors and adapters as described in Section 6.
- Step 3:** Install connectors into the adapters at the rear of the adapter panels (Figure 9).
- Step 4:** Route fiber slack through the routing clips on the fiber shelf.




Figure 9

### 5.2 Install Cable Using Buffer Tube Fan-out Kits

- Step 1:** Terminate the fibers according to the instruction provided with the BTF kit (purchased separately).
- Step 2:** Feed the fan-out body and connectors through the entry grommet (Figure 10).
- Step 3:** Slide the fan-out body into the cut-out in the fiber shelf with the rings on the fan-out body beneath the shelf. Secure fan-out with a cable tie (Figure 10 inset).
- Step 4:** Remove the blank panels from the unit and replace with connector panels (purchased separately).

- Step 5:** Clean connectors and adapters as described in Section 6.
- Step 6:** Install connectors into the rear of the adapter panels.
- Step 7:** Route fiber slack through the routing clips on the fiber shelf.




Figure 10

### 5.3 Install Connector Modules

Remove the blank panels from the front of the unit and replace with the connector modules (purchased separately).




Figure 11

## 5.4 Install Cable Using Splice Trays

A splice tray bracket kit (p/n PC4-SPLC-12SR, purchased separately) is required to install splice trays. Follow instructions provided with the splice tray bracket kit.

## 5.5 Documentation

Record fiber identification information appropriately on the provided identification label stored beneath the fiber routing plate (Figure 11). Accurate record keeping is imperative for an organized installation.

## 5.6 Reinstall Doors

If the front or rear doors were removed, reinstall them at this time.

## 5.7 Route Jumpers (Patch Cords)

**Step 1:** Remove dust caps from the connectors and adapters into which they will be mated. Refer to Section 6 for recommended cleaning instructions. Clean connector end-faces and adapters per standard company practices and insert connectors into adapters.

**Step 2:** Install jumpers as specified by company planning diagrams.

**Step 3:** Route jumpers through the clips at the front of the housing.

## 6. Connector Care and Cleaning



**WARNING:** Isopropyl alcohol is flammable with a flashpoint at 54°F. It can cause irritation to eyes on contact. In case of contact, flush eyes with water for at least 15 minutes. Inhalation of vapors irritates the respiratory tract. Exposure to high concentrations has a narcotic effect, producing symptoms of dizziness, drowsiness, headache, staggering, unconsciousness and possibly death.

- Always keep dust caps on connectors and adapters when not in use.
- Ensure dust caps are clean before reuse.
- Use optical cleaning materials as standardized by your company.
- Clean the connector before every mating, especially for test equipment patch cords (jumpers).
- A minimum level of cleaning is listed below. Local procedures may require more rigorous cleaning methods.

**Step 1:** Remove plugs from the connector adapter.

**Step 2:** Wipe the connector ferrule twice with a lint-free wiping material moistened with isopropyl alcohol. Then wipe across the end of the ferrule.

**Step 3:** Repeat previous step with a dry wipe.

## 7. Maintenance

The unit requires very little maintenance to ensure fibers and parts remain in good condition.

- External components may be cleaned occasionally with a damp, nonabrasive cloth.
- Check nuts, bolts, and screws; tighten as needed.
- Check fiber optic cable to make sure bends do not exceed the minimum bend radius.
- Check cables for unnecessary strain, for crimping or crushing at entries and exits, and for damage.
- Check unit record labels to make sure all are clear and accurate.

---

**Corning Optical Communications LLC • PO Box 489 • Hickory, NC 28603-0489 USA  
800-743-2675 • FAX: 828-325-5060 • International: +1-828-901-5000 • [www.corning.com/opcomm](http://www.corning.com/opcomm)**

Corning Optical Communications reserves the right to improve, enhance, and modify the features and specifications of Corning Optical Communications products without prior notification. A complete listing of the trademarks of Corning Optical Communications is available at [www.corning.com/opcomm/trademarks](http://www.corning.com/opcomm/trademarks). All other trademarks are the properties of their respective owners. Corning Optical Communications is ISO 9001 certified. © 2007, 2015 Corning Optical Communications. All rights reserved.

---